



**NOTES:**

1. SEE SPECIFICATIONS FOR PLANTING SOIL REQUIREMENTS.
2. PROVIDE 100 HIGH EARTH SAUCER AROUND SHRUB BED WITH 100 WIDE SMOOTH BED EDGE TO RETAIN MULCH.
3. REMOVE SHRUB POT AND SCARIFY ROOT BALL BEFORE PLANTING.
4. ALL MEASUREMENTS ARE IN MILLIMETRES UNLESS STATED OTHERWISE.